

# Mixer nozzle ISL

SORMAT CODE 9640072603



**Hi-end mixer nozzle with ITH resin means that anchoring is always a success**

- Common two-component chemical anchoring
- Resins mix in the mixer nozzle. Squeeze a test strip of min. 10 cm out until you see the two different-colored components completely mixed.
- Sormat ITH range cartridges are always equipped with one or two mixers. A stiff spiral inside the mixer allows the resin to flow and mix properly. Use only homogeneously mixed resins!
- In general, you can store partially used cartridges with the mixer on. Change mixer before reusing.
- If the drill hole is deep, the 200 / 250 mm long mixer nozzle extension ISL EXT can be used with ISL to reach the bottom of the hole.

## PRODUCT OVERVIEW

---

<b>Other codes</b>	SNRO 1356525 /
<b>Packages</b>	box (bag): 10 / outer carton: 100
<b>Weight</b>	6.5 kg / 1000

## APPLICATIONS

---

- For injection resins