

Mixer nozzle SE1000

SORMAT CODE 9570040142



Hi-end mixer nozzle with ITH resin means that anchoring is always a success

- Common two-component chemical anchoring
- Resins mix in the mixer nozzle. Squeeze a test strip of min. 10 cm out until you see the two different-colored components completely mixed.
- Sormat ITH range cartridges are always equipped with one or two mixers. A stiff spiral inside the mixer allows the resin to flow and mix properly. Use only homogeneously mixed resins!
- In general, you can store partially used cartridges with the mixer on. Change mixer before reusing.
- If the drill hole is deep, the 200 / 1000 mm long mixer nozzle extension ISL EXT can be used with ISL to reach the bottom of the hole.

PRODUCT OVERVIEW

Other codes	/
Material	Polyethylene
Packages	box (bag): 10
Weight	11.0 kg / 1000
GTIN-13	4061245102603

APPLICATIONS

- For injection resin SE1000 Seismic