

## Plasterboard fixing KLA met (10 DIY)

SORMAT CODE 9640095602



# Self-drilling metallic quickie for fixing into gypsum plasterboard walls

- Fire-proof self-drilling anchor for standard and composite gypsum plasterboard walls and gypsum fibreboard walls.
- Predrill with a 8 mm drill bit when fixing to gypsum fibreboard and double-planked gypsum plasterboard.
- The quickest way to fix light objects. No special tools needed, just a PZ2 screwdriver. Set flush with the board surface, do not overtighten.
- Equipped with a 4,5 x 35 mm ZP screw. Can also be used with other suitable wood- and self-tapping and chipboard screws, hookscrews and eyescrews.
- ZP for dry indoor and temporary outdoor use.

#### PRODUCT OVERVIEW

Other codes SNRO 1372069 /
Material Zinc die casted
Packages box (bag): 10 / outer

carton: 100 / piece: 1

Weight 6.3 kg / 1000

#### **APPLICATIONS**

- Pictures
- Paintings
- Lighting
- · Coat hangers
- Electrical installations

#### **BASE MATERIALS**

#### ALSO SUITABLE FOR


- · Gypsum plasterboard
- Gypsum plasterboard composite

#### Technical data

#### **INSTALLATION DETAILS**

Length (L)	31
Max. fixture thickness (Tfix )	12
Min. sheet thickness (T <sub>sheet, min</sub> )	9
Free space behind the sheet	19
Suitable screws Diameter	4,5 x 35

## Performance data



## Installation

